

Hydro Trailer Kit

NOTE: Read the installation instructions thoroughly before beginning the installation process. Retain these Installation Instructions with your Accessories and Options manual.

Kit includes:

QTY.	DESCRIPTION
1	Hydro Trailer
1	Bottom Pad
1	Top Pad
1	Hitch Plate
4	Flat-Head Machine Screw (5/16-18 x 1 1/2 in.)
4	Washer (small)
1	Washer (large)
1	Allen Wrench
4	Nylon Lock Nut
2	Cap Screw (3/8-16 x 5 in.)
2	Washer (3/8 in. I.D.)
1	Lock Nut
1	Tow Bar
1	Pin
1	Flag
1	Instructions

*Included

INSTALLING HITCH PLATE

1. Center the hitch plate on the rear of the deck leaving approximately 3 mm (1/8 in.) clearance between the hull trim and the hitch plate pin sleeve.
2. Using a grease pencil and the hitch plate as a template, mark the locations of the forward outer and rear inner mounting holes on each side of the hitch plate.
3. Using an 1/8 in. drill bit, slowly drill a pilot hole through the hull trim and deck at each mounting hole mark; then using a 5/16 in. drill bit, enlarge the four pilot holes.

CAUTION

Care must be taken when drilling holes in the deck. Drill slowly through the fiberglass and the gelcoat or it will chip. Covering the area to be drilled with masking tape will help to prevent chipping.

Fig. 1

